

LCD CHIP

Control and Clarity in a chip

- Light On/Off
- Alert / Reminder
- App Connected

- Light ON/OFF: Long Press **DOWN**.
- Walk Assist: Long Press **UP** to Unlock, then Hold **UP** to start.
- APP Connect: Double Click **POWER**

SYSTEM STATUS



- ON/OFF**
- ON: Long Press
- OFF: Long Press

Short Press **LEFT** **RIGHT** to switch between information items.


Press **UP** / **DOWN** to switch levels.

- SPORT
- TOUR
- ECO
- OFF


MAIN INFORMATION

Short Press **LEFT** **RIGHT** to switch between ODO/Trip-distance /Trip-time/Avg-speed.

BATTERY LEVEL



SMARTLY CONNECT YOUR E-BIKE



Download Hyena Rider Assistant. Elevate your ride with a dynamic dashboard, riding data analysis, smart e-bike management, OTA updates, and personalized settings, for an unparalleled riding experience.



Android



iOS